

When using reflective tapes, the Reflectivity vary by the size of the tape.

Please refer to the ' Reflectivity by Reflective Tape Model' table before using the tape.

※2: Non-glossy white paper 50×50mm.

※3: It will vary by the installation environment and sensing conditions.

Please refer to the 'O Conditions of min. sensing target and installations (retroreflective type)'.

%4: The weight includes packaging. The weight in parenthesis is for unit only.

The temperature or humidity mentioned in Environment indicates a non freezing or condensation.

Feature Data Through-beam type

BTS1M-TDTL / BTS1M-TDTL-P



© Retroreflective type • BTS200-MDTD / BTS200-MDTD-P



© Retroreflective type • BTS200-MDTD / BTS200-MDTD-P





© Convergent reflective type • BTS30-LDTL / BTS30-LDTL-P



• BTS15-LDTL / BTS15-LDTL-P





Operating Timing Diagram



% The waveforms of "Operation indicator" and "Transistor output" are for Light ON operation. They are reversed for for Dark ON operation.

Dimensions

Through-beam type

(unit: mm)





Autonics





Sub-bracket for through-beam type



%The sub-bracket for each sensing type is included bracket A (B).

• Reflector (MS-6)



• Reflective tape (sold separately)





• Bracket B (sold separately)



• Sub-bracket for reflective type

2-M2 Tap



• Slit (BTS1M-ST, sold separately)

0.2

• Slit (BTS1M-ST-T, sold separately)





(B) Fiber Optic Sensors

(C) LiDAR

(D) Door/Area

(F) Proximity Sensors

(H) Rotary Encoders

Boxes/ Sockets

(I) Connectors/ Connector Cables/ Sensor Distribution

Sensors

(E) Vision Sensors

(G) Pressure Sensors

Mounting and Sensitivity Adjustment

O Installation

When installing the product, tighten the screw with a tightening torque of $0.3N{\cdot}m.$

unit or bend the cable section. The inside unit may be wet.



%Cautions during installation of convergent reflective type

1)Make sure that the sensing side of this sensor is parallel to the surface of each object.



2)Make sure to install the sensor after carefully considering the moving direction of the sensing objects. Refer to the illustration below:



Optical axis adjustment

Through-beam type

Set the emitter and the receiver facing each other. Adjust the emitter or the receiver up, down, left, right and fix the unit at the center point of where the stability indicator is operating.



Retroreflective type

Place the sensor and the reflector (MS-6) or reflective tape facing each other. Adjust the reflector up, down, left, right and fix the reflector at the center position where the stability indicator is operating.

Make sure that the sensing side of the sensor is parallel to the surface of the reflector.



%Please use reflective tape (MST Series) for where a reflector is not installed.

• Convergent reflective type

Place the sensing target, then adjust the sensor up, down, left, right and fix the sensor at the center position where the stability indicator is operating.

Make sure that the sensing side of the sensor is parallel to the surface of each object.



© Conditions of min. sensing target and installations (retroreflective type)

When installing the retroreflective photoelectric sensor, be sure to check the moving direction of sensing targets. Please refer to the [Figure 1, 2].

As the [Figure 3], please consist the center between the sensor and the reflector (MS-6) or reflective tape, and check the stable Light ON operations (operation (red) / stability (green) indicators turn ON). Min. sensing target is detected 100mm away from the sensor (example).



%The size of minimum sensing target will vary by the installation environment of the reflector (MS-6) and the sensing position and material of the sensing target.

Reflectivity by Reflective Tape Model

MST-50-10 (50×50mm)	95%
MST-100-5 (100×100mm)	100%
MST-200-2 (200×200mm)	100%

%This reflectivity is based on the reflector (MS-6).

%Reflectivity may vary depending on usage environment and installation conditions.

The sensing distance and minimum sensing target size increase as the size of the tape increases.

Please check the reflectivity before using reflective tapes.

%For using reflective tape, installation distance should be min. 20mm.

Accessory (sold separately)

BTS1M-ST



**This slit is for BTS1M-TDT_- only.
Attach only to the emitter to use.
**4 pieces are packed and sold separately.
**This alt is sticker for attachment place.

**This slit is sticker for attachment, please remove the dirt on lens of photoelectric sensor before using it. After attaching the slit, remove the front protection film.

XMin. sensing target and max. sensing distance by Ø of the slit when attach the slit at an emitter.

Slit Ø	Min. sensing target	Max. sensing distance
Ø1	Opaque materials of min. Ø1.6	500mm

• BTS1M-ST-T



☆This slit is for BTS1M-TDT_H only. ☆This slit can be used in Ø1 or Ø0.5 by its installation direction. %2 pieces are packed and sold

separately. % This slit is made of SUS. After covering the product with the slit, fix them with the bolts and sub-bracket.

XMin. sensing target and max. sensing distance by Ø of the slit

	•	0	0		
Slit Ø	Applied condition			Max.	Feature
	Emitter Receiver	Pocoivor	Min. sensing target	sensing	data
			distance	number	
Ø1	Applied	—	Opaque materials of min. Ø1.6	500mm	1
	—	Applied			
	Applied Applied	Applied	Opaque materials	300mm	2
		Applied	of min. Ø1.2		
Ø0.5	Applied	—	Opaque materials of min. Ø1.2	300mm	3
	—	Applied			
	Applied Applied	Opaque materials	100mm	(4)	
		Applied	of min. Ø0.8	TOOTIIT	1 (4)

Feature data ① Feature data 2 1 2 1 2 1.0 1.0 E Ê 9.0 distance (1 distance 0.8 0.6 Seusing 0.2 පි 0.4 Sens 0.2 0 0 20 10 0 -10 -20 -30 30 20 10 0 -10 -20 -30 30 Center Right Center Right Left Left Sensing area (mm) Sensing area (mm) Feature data ③ Feature data ④ 1.2 0.14 Ê 0.12 Ê 1.0 0.10 distance පී 0.8 0.08 distai 0.6 0.06 Sensing 0.2 Sensing 0.04 0.02 0 0 30 20 10 0 -10 -20 -30 10 5 Ω -5 -10 Left Center Right Left Center Right Sensing area (mm) Sensing area (mm)

A) Photoelectric Sensors

SENSORS

CONTROLLERS

MOTION DEVICES

(B) Fiber Optic Sensors

(C) LIDAR

(D) Door/Area Sensors (E)

Vision Sensors (F) Proximity

Sensors

(G) Pressure Sensors

(H) Rotary Encoders

Encoders (I)

Connectors/ Connector Cables/ Sensor Distributior Boxes/ Sockets